



8502

CITY SLIZER

LEGO Technic

4124714






1




2



3



4



5




6




7




8





9




11




12




13




14




15








1



2



3



4



8500

+



8501

+



8502

+



8503



1



2



3



4



5



1



2



6



7





8



9



10



11



12



1



2



3




1



2



4



5



6



7

